Huron Fleece Tech Jacket



DF7670

Product Features:

- 15.5-oz, 100% polyester fleece
- 5.4-oz, 100% DWR nylon panels at upper body, sleeves and hem
- Zippered hand pockets with polyester tricot lining
- Drawcord and toggles at hem

Adult sizes: XS-4XL

Icons/Fabric Features:



Available Colours and PMS Colours

Textile fabric colours are subject to dye lot variation and will not be exact match to print pantone reference

BLACK / BLACK



ASPHALT / BLACK



WARMTH RATING	MILD	● WARM	WARMER	WARMEST
WATER PROTECTION	● WATER RESISTANT PANELS		WATERPROOF	
WIND RESISTANT	YES			
WIND AND WATER PROTECTION	DWR PANELS			

Due to the nature of nylon, special care must be taken throughout the decoration process.

DISCONTINUED

DF7670 - DryFrame® Huron Fleece Tech Jacket

GARMENT MEASUREMENTS								
Size	**XS**	**S**	**M**	**L**	**XL**	**2XL**	**3XL**	**4XL**
Chest - *Half Measure*	20 1/4"	21 3/4"	23 1/4"	24 3/4"	26 1/4"	27 3/4"	29 3/4"	31 3/4"
Chest - *Full Measure*	40 1/2"	43 1/2"	46 1/2"	49 1/2"	52 1/2"	55 1/2"	59 1/2"	63 1/2"
Body Length from HPS (At Front)	28"	28 1/2"	29"	29 1/2"	30 1/2"	31 1/2"	32"	32 1/2"
Sleeve Length-CB	34 3/4"	35 1/2"	36 1/4"	37"	37 3/4"	38 1/2"	39 1/4"	40"

Finished measurements in inches. Refer to "How to Measure" guide for detailed information on measurement instructions.

ADULT General Sizing Guide								
Size	**XS**	**S**	**M**	**L**	**XL**	**2XL**	**3XL**	**4XL**
Chest	30"-32"	34"-36"	38"-40"	42"-44"	46"-48"	50"-52"	54"-55"	56"-57"
Waist	26"-29"	29"-32"	32"-35"	35"-38"	38"-41"	41"-44"	44"-47"	47"-50"
Sleeve Length-CB	31"-32"	32"-33 1/2"	34"-35"	35"-36"	36"-37"	37"-38"	38"-39"	38 1/2"-39"

DRYFRAME®
CONTROL YOUR CLIMATE®

PRINTING INSTRUCTIONS FOR NYLON FABRICS

Due to the nature of Nylon fabric, special care must be taken throughout the decoration process. Special care must be taken during the decoration process and after.

Here are some tips to effectively decorate these products.

Heat Transfer/Screen Printing:

- Garment temperature must not exceed 310°F or 154°C.
- Use fast fushion/low cure temperature ink to help prevent the need for a higher temperature to cure the ink.
- A test sample run is recommended in all printing processes, especially if you have a large order or if your printer does not specialize in printing on Nylon fabrics.